



INSTRUCTION MANUAL

Model: RS-939


Thank you for purchasing the digital Bluetooth speaker Sami RS-939. Read the instructions carefully to obtain optimum results and preserve it for future references.

MAIN FEATURES

- 1. Radio: The speaker comes with FM radio function and facilities an automatic search and storage of radio channels..
- 2. The portable speaker reproduces high quality sound Bluetooth 2.4G. The version of the Bluetooth is 3.0.
- 3. SUPER BASS. This device allows you enjoy the digital quality sound.
- 4. AUX 3.5mm/line-in. Reproduces music from other devices when connected by means of the audio cable (included).
- 5. Hands-free. Allows to answer incoming calls in Bluetooth mode.
- 6. Range 10m.
- 7. Micro SD card. Reads micro SD cards in Mp3 format.
- 8. Microphone. The integrate mic is used in the hands-free mode to speak.
- 9. Powerful sound.
- 10. USB. Reads USB in Mp3 format.
- 11. Rechargeable battery. The device has an integrated, rechargeable and long lasting Li-ion battery of 600 mAh .
- 12. The RS-937 has two speakers and reproduces music with great clarity.
- 13. Rotating. This speaker has a unique rotative design and permits a 360° turn and is also dismountable from the base.

POINTS TO REMEMBER

- 1. Charge the battery completely before use.
- 2. Only use the DC 5V micro USB cable (included) to charge the speaker and to connect it to your computer.



KEY FUNCTIONS

1. **Mic:** Micrófono: Estando en modo manos libres puedes utilizar este micrófono para atender la llamada.
2. **LED indicator:** There are two colors, red and blue. When the LED is a constant blue light it indicates that the speaker is on and enters the Bluetooth mode automatically. To change to radio mode double click on this button and while in radio mode the LED light remains constantly blue.
3. << - In music play mode, this key allows you to access the playlist backwards; in radio mode it permits you to hear the radio channels backwards and is also used to reduce the volume level of the speaker.
4.  ON/OFF/hands free. To switch on the RS-939, long press this key. The speaker enters the Bluetooth mode, while in this mode you can press this key once to answer incoming calls. To enter the radio mode, double click on this key (as you would click on the mouse of the computer) and while in this mode press this key once to start an automatic search and storage an FM channels on the radio.
5. >> + This key allows you to access the playlist and radio channels, upwards and is used to increased the volume.
6. AUX/line in 3.5mm .
By means of this cable you can connect your speaker to any device (mobile, Mp3, tablet etc) to replay music stored in them
7. Micro SD card slot.
8. Micro USB. Connect the DC 5V USB cable (included) to your computer to charge your speaker or to reproduce music (in case the battery is not fully charge).

Bluetooth: when you switch on the RS-939, it enters the Bluetooth mode by default. Activate the Bluetooth function on your mobile. Initiate search for device, and when RS-939 appears on the screen, select the device and pair it with your speaker. Now you can sit back and enjoy listening to your favorite music or use it in hand free mode to answer calls.

CONTENTS

- One RS-939 speaker
- One DC5V micro USB cable
- One AUX/line in 3.5 mm cable
- Instruction manual
- Warranty card

SAFETY INSTRUCTIONS

- Do not cover the speaker with any object.
- Avoid using the speaker in extreme weather conditions.
- Keep away from inflammable substances.