

Sami[®]

WEARABLE
User Manual
WS-2318

RUNNING 2

S M A R T B A N D

Thank you for purchasing the **Sami** wearable WS-2318. Read the instructions carefully to obtain optimum results and preserve it for future reference.

· DESCRIPTION OF THE WEARABLE.



CONTENTS.

Wearable, USB cable, instruction manual.

CHARGING.

To charge the smart bracelet take out the device from the strap. Connect the SMART BRACELET RUNNING 2 to a computer or laptop with the USB cable for charging. Kindly use only the USB cable included with the wearable. If you use a power adapter for charging, the output of the power adapter should be 5V, 1A. Charging time: 2~3 hours. Please charge the device fully before using.



HOW TO POWER ON / POWER OFF?

- 1) To turn ON the bracelet, on the screen, long press the touch button for a few seconds to make it Power On. The touch button is situated on the bottom of the screen.
- 2) To turn OFF the bracelet, short press the touch button until the OFF icon of the menu appears in the screen. Then long press the touch button for a few seconds and the smart band will turn off.

GETTING STARTED:

- For Android

- 1) How to obtain the BT Connection APK (**LEFUN HEALTH**)

Please go to the PLAY Store and search LEFUN HEALTH and install the app, or go to our **website www.sami.es** and download the application.

- 2) Installation the LEFUN HEALTH APK.

When installing the LEFUN HEALTH application on your Android, you must allow all the Application Permissions, allow this LEFUN HEALTH app auto run.

The first time you run this LEFUN HEALTH, it will ask you to Enable Notifications, please tap OK and tap the LEFUN HEALTH and confirm OK.

- 3) How to make the wearable pair with your Android smart phone?

*First, turn on the Bluetooth of your Phone.

*Second, run the LEFUN HEALTH app on your Phone, on the home page of LEFUN HEALTH, select the main menu situated in the top left of the screen and select "**no device connected / Lefun not connected**", **tap search**, wait a few seconds and select the Bluetooth named "**LEFUN**" or "**WS-2318**" to make it pair. The pairing will be finished in a few seconds. In the main menu of the apk, it will appear Lefun/connected, and in the left top of the main screen of your smart band an icon of two blue arrows will also appear showing your smart band is connected. If only one arrow appears, this means your smart band is not connected.

*Now you can start using your desired functions of the smart band.

- For iPhone

1) How to obtain the BT Connection APP? (LEFUN HEALTH)

On iPhone, please go to APP Store and search LEFUN HEALTH and install the app.

2) How to make the wearable pair with your iPhone?

*Turn On the Bluetooth of the iPhone

* Run the LEFUN HEALTH app on the iPhone, on the home page of LEFUN HEALTH, , select the main menu situated in the top left of the screen and select "**no device connected / Lefun not connected**", **tap search**, wait a few seconds and select the Bluetooth named "**LEFUN**" or "**WS-2318**" to make it pair. The pairing will be finished in a few seconds. In the main menu of the apk, it will appear Lefun/connected, and in the left top of the main screen of your smart band an icon of two blue arrows will also appear showing your smart band is connected. If only one arrow appears, this means your smart band is not connected.

*Now you can start using your desired functions of the smart band.

PRODUCT FEATURES.

· **BLUETOOTH (V 4.0).**

· **FIXED-POINT TOUCH CONTROL** (Tap to select & view functions, or tap to select to Power On/Power OFF.)

· **TOUCH SCREEN.** touch screen 0.96"

· **BUILT IN VIBRATING MOTOR.**

· **BUILD IN HEART RATE SENSOR.**

· **BUILD IN GRAVITY SENSOR**

DISPLAY SCREEN INTERFACE

1) Time/Date displaying (Synchronize time and date with your smart phone)

2) Steps (Pedometer)

3) Distance (Pedometer)

4) Calories (Pedometer)

5) Heart rate

6) Blood Pressure Test

7) Blood Oxygen

8) Find Phone

9) Messages

10) About

11) Power Off

Data can be sync from the wearable to smart phone on the LEFUN HEALTH APK/APP.

FUNCTIONS.

PHONE CALL NOTIFICATION - vibrating reminder for incoming phone calls

MESSAGE NOTIFICATION - vibrating reminder for incoming messages, including SMS, WhatsApp, Facebook, Twitter, Skype messages, etc.

GPS MAP TRACE - (view it on the BT APP/APK LEFUN HEALTH). On the bottom of the home page of the LEFUN HEALTH app select the Sport icon, tap on the play/start button and allow the GPS permissions. Then select the GPS ICON (situated in the right bottom of the screen) to view the map. Tap again in the Sport icon and select the sports history icon (situated on the bottom left of the screen), there you can see your sports history. If you tap on them you can see the GPS trace in the map.

SLEEP MONITOR - supported in the LEFUN HEALTH APK/APP

SEDENTARY REMINDER - supported in the LEFUN HEALTH APK/APP

DRINK REMINDER - supported in the LEFUN HEALTH APK/APP

ALARM CLOCK - supported on the LEFUN HEALTH APK/APP

RAISE YOUR HAND TO LIGHT UP THE SCREEN - supported on the LEFUN HEALTH APK/APP

SHAKE THE SMART BAND TO TAKE PICTURES FROM YOUR MOBILE CAMERA - supported on the LEFUN HEALTH APK/APP

TECHNICAL SPECIFICATIONS:

Display screen: Capacitive touch screen IPS 0.96".

Internal memory: 512KB+16KB

Charge I/O port : Micro USB 5 pin charging.

Battery: Built in Li-Polymer 90 mAh

Stand by time: 20 DAYS

Working time: 5 DAYS

Bluetooth: V4.0.

Exterior Dimensions: 255x18x12 mm

Net Weight: 18.4 g

Water-resist Rating: IP67 (this device resists raindrops, it's not water proof)

Declaration of Conformity

Hereby we,

Name of manufacturer: SANTOSHI SL
Address: CALLE FELIPE ASENJO N.56
Zip code & City: 28947 - FUENLABRADA (MADRID)
Country: SPAIN

declare that this DoC is issued under our sole responsibility and that this product:

Product description: Smart Band
Type designation(s): WS-2318
Trademark: SAMI WEARABLE

is in conformity with the relevant Union harmonization legislation:

DIRECTIVE EMC

Standard CE (EC & R & TTE): DIRECTIVE 1999/05/CE

Standard ROHS: 2011/65/EC: restriction of dangerous substances.

with reference to the following standards applied:

EN60950-1/A2:2013

EN300328v1.8.1

EN301489-1v1.9.2

EN62479:2010



Signature

Full name: VISHAL MIRPURI

Position: ADMINISTRATOR

Date: 22 / 11 / 2018