

# Sami<sup>®</sup>

## WEARABLE

Instruction Manual  
Model: WS-2303

Thank you for purchasing the **Sami** wearable WS-2303. Read the instructions carefully to obtain optimum results and preserve it for future references.

### MAIN FEATURES:



1. Compatible with Android/iPhone.



2. This wearable can be paired to your smart phone by Bluetooth.



3. The wearable can be used in vibration mode.



4. Supports multiple languages .



5. Phone book. You can access the phone list of your smart phone through your wearable.



6. It vibrates when an incoming call.



7. Identification of incoming calls.



8. Anti lost function 15m.



9. Permits you to check Whatsapp or any PUSH messages.



10. Allows you to check Facebook notifications.



11. Built in alarm clock.



12. Pedometer.

### HOW TO OBTAIN THE REQUIRED APPLICATION:

- Before you use your Sami wearable please open the following link [www.sami.es/smartwatchWS2303](http://www.sami.es/smartwatchWS2303)

**Note:** This application is only operative with Android devices. The IOS devices have limited functions and the connect to your wearable only by Bluetooth.

- Or if you have the QR code reader already installed on your smart phone scan the below code





**FUNCTION AND KEY DESCRIPTION:**

- The wearable has one button at the base of the display and works by pressing the extreme left and extreme right of this button . For easy understanding we will call them as left key and right key.
  - Left key functions: Long press this key to switch on/off the wearable when it is in stand by interface. Short press to return to the stand by interface. In the menu, long press to select the next function and while you are in the menu if you receive a call press this key once to reject the call. In case the wearable does not repond press the key for 7/8 seconds to reset.
  - Right key functions: When the wearable is in stand by, display, short press the right key to enter the main menu and press once again to confirm your option in the main menu. In case you receive a call press this key to stop vibrations.
  - USB. On the reverse of the wearable you will find an USB icon on the watch band. Unplug it to reveal the USB. Use it to charge the wearable by connecting it to the USB port of your computer.
- You can also use an adapter with the required voltage specifications to charge your wearable with the help of the USB cable.

1. Look at the underside of the wearable. You will see the following icon in one extreme of the watchband.



2. Pull out the watchband where the icon is and USB is exposed. Connect it to the USB port of the computer to charge the wearable.



3. Adapter. (optional) It is extremely important to follow voltage specifications.



4. Follow carefully instructions on how to connect the USB cable of the wearable to the adapter.



**THE MAIN MENU INCLUDES:**

1. Pedometer. Is used to calculate the distance walked (hours, minutes and seconds) and number of Km. When you click on this function you will see the following menu.

- Pedometer. Short press the right key to enter this menu and short press it again to activate the pedometer.
  - Last record. Gives you information of total number of steps, total distance covered, calories burn and walking time of the last lap walked.
  - Step setting. Set step/stride size (cm).
  - Weight setting. Set weight (kg).
2. Sleep monitor allows you to monitor the quality of your sleep.
  3. Phone book. Once the wearable has been successfully connected and synchronized to your smart phone it displays phone contacts.
  4. Distance alert. When the watch is more than 15 m away from the mobile, it vibrates to inform the wearer that the two devices are not close-by. This is helpful to prevent loss or theft of the mobile. (Ensure that this function is activated). When you click on the menu of this option you will see the following submenu.
    1. Open.
    2. Close
  5. Set time. Short press the right key to enter time setting interface. Long press the right key to move to the right. Short press the left key to change the number and short press this key again to complete setting.
  6. Set date. Short press the right key to enter date setting interface. Long press the right key to move to the right. Short press the left key to change the number and short press this key again to complete setting.
  7. Alarm. Short press the right key to enter the alarm time interface. Long press left key to move down to set the time.
  8. Bluetooth. Once you click on this option the following menu will be display:
    - Bluetooth dialer. Search for WS-2303 amongst devices when Bluetooth is switch on and connect it to your smart phone.
    - Bluetooth settings. Enables you to change the name of the wearable.
  9. Organizer. Has the following 2 options in its menu:
    - Language. You can choose between spanish or english.
    - Stopwatch. Short press the right key to start/stop this function.
  10. Camera. You can access the camera of your mobile from your wearable.
  11. Find phone. When you click on this function your phone will ring. This is useful to locate your smart phone.

**· Warning: Between the two operative systems android and iOS, there is a possibility that some of the features of the wearable do not function as they should with the iOS. It is important to mention that smart phones use different versions of the android operation system and there is a probability that all the features of the wearable may not function optimally.**

#### **TECHNICAL SPECIFICATIONS:**

**Display screen: 0.91 " OLED**

**Screen resolution: 128x32 pixels.**

**Charge I/O port: Micro USB 5 pin.**

**Battery: Built in Li-Polymer 150 mAh**

**Stand by time: 120-150 hours**

**Charging time: 2~3 h**

**Current. 200 mAh**